

## Z8038000ZAS

Z80380 ASSEMBLER, LINKER AND LIBRARIAN

#### GENERAL DESCRIPTION

#### The Z80380 Macro Assembler

The Z80380 Macro Assembler (ZASM) generates relocatable object code modules in IEEE 695 OMF format. The assembler also handles macros and conditional assembly, eliminating the need for a macro preprocessor.

#### The Z80380 Linker

The Z80380 Linker (ZLINK) links object modules produced by the assembler. The linker produces two files:

- an absolute object file in Motorola S-record format, and
- an optional comprehensive linkmap file.

Linking offers the benefits of:

- smaller, faster-assembling modules,
- use of local and global variables, and
- ease of relocating to a specified address.

Linking lets the user develop commonly-used routines separately, test them, and link them to programs under development.

#### The Z80380 Librarian

The Z80380 Librarian (ZLIB) is the librarian facility. The librarian can be used to place the relocatable object files in a library. In this way, the user can collect user-defined modules which allows commonly used routines to be easily included in programs.

### Requirements

The PLC Z80380 Macro Assembler/Linker/Librarian requires an IBM® PC or true compatible with:

- DOS 5.0 or higher
- 5 Mbytes of hard disk space
- floppy drive
- mouse
- 80386 or 80486 CPU
- 4 Mbytes of RAM

# Device Supported Z80380/Z80180/Z84C00

Software (IBM PC platform)

Assembler, linker, librarian

#### Documentation

**Kit Contents** 

Macro Assembler/linker/librarian User's Guide. Registration Card.

<sup>\*</sup> IBM is a registered trademark of International Business Machines Corp.

© 1993 by Zilog, Inc. All rights reserved. No part of this document may be copied or reproduced in any form or by any means without the prior written consent of Zilog, Inc. The information in this document is subject to change without notice. Devices sold by Zilog, Inc. are covered by warranty and patent indemnification provisions appearing in Zilog, Inc. Terms and Conditions of Sale only. Zilog, Inc. makes no warranty, express, statutory, implied or by description, regarding the information set forth herein or regarding the freedom of the described devices from intellectual property infringement. Zilog, Inc. makes no warranty of merchantability or fitness for any purpose. Zilog, Inc. shall not be responsible for any errors that may appear in this document. Zilog, Inc. makes no commitment to update or keep current the information contained in this document.

Zilog's products are not authorized for use as critical components in life support devices or systems unless a specific written agreement pertaining to such intended use is executed between the customer and Zilog prior to use. Life support devices or systems are those which are intended for surgical implantation into the body, or which sustains life whose failure to perform, when properly used in accordance with instructions for use provided in the labeling, can be reasonably expected to result in significant injury to the user.

Zilog, Inc. 210 East Hacienda Ave. Campbell, CA 95008-6600 Telephone (408) 370-8000 Telex 910-338-7621 FAX 408 370-8056